

Neusilin®

Increased Production of Oyster Mushroom on addition of Neusilin® FH1



Neusilin® is a synthetic form of Magnesium aluminometasilicate which is generally used as pharmaceutical excipients. Due to its high water/oil absorption capacity and unique physico chemical properties. **Neusilin®** can be used in a variety of applications ranging from pharmaceutical, cosmetic and hygiene products. In this newsletter, we describe a novel use of **Neusilin®** where addition of small amounts to the culture media increases mushroom cultivation yields.

Method

<p>1) Preparation (Two days before Hypha cultivation)</p>	<p>Mix with saw dust and rice bran/wheat bran in 3 : 1 ratio and add water to retain the moisture at 65% Add Neusilin® FH1 and mix to get a homogenous mixture Add 560-570 g of the media in each bottle (850mL) and sterilize at 100°C. 1 , 3 or 6g of Neusilin® FH1 was added per bottle.</p>
<p>2) Hypha cultivation (First day)</p>	<p>Inoculate the hypha. Incubate at 18-20°C, Humidity 70-80%RH</p>
<p>3) Germination & growth (After 29 days)</p>	<p>Remove old hypha and expose new hypha. Further growth at 15°C, Humidity 80-90%RH</p>
<p>4) Harvest (After 41 days)</p>	<p>Harvest</p>

Flow diagram of the cultivation process




Table 1. Yield of Oyster Mushroom on addition of Neusilin®

Bottle No.	Neusilin® FH1 (g/bottle)		
	0	1	6
1	52	66	100
2	48	64	100
3	44	55	100
4	59	68	92
5	49	72	96
6	42	66	92
7	40	64	104
8	48	54	100
9	44	54	100
10	55	66	103
11	40	66	100

12	44	53	97
13	52	57	84
14	52	-	81
15	40	-	-
16	48	-	-
Average	47.3	61.9	96.4

Addition of 6g of Neusilin® FH1 per 560-570g of culture media/bottle resulted in almost 100% increase in the yield of Oyster mushroom.

Typical properties of Neusilin® grades:

Grade	FH1	FH2	S1	US2	UFL2
pH of 5% Slurry	9.7	9.7	9.4	7.4	7.4
Form	Powder	Powder	Granule	Granule	Powder
Oil Absorbing Capacity	1.3 ml/g	1.5 ml/g	1.3 ml/g	3.2 ml/g	3.2 ml/g
Particle Size Distribution	10-20 mm*	10-20 mm*	70-110mm	60-120mm	2-8 mm*
Residue 330 Mesh sieve	<10%	<10%	-	-	<0.5%
Specific Surface Area	110 m2/g	110 m2/g	110 m2/g	300 m2/g	300 m2/g
Angle of Repose	45°	45°	30°	30°	45°
Bulk Density (Loose)	0.27-0.34	0.31 g/ml	0.33 g/ml	0.15 g/ml	0.08 g/ml
Bulk Density (Tapped)	0.36-0.45	0.43	0.4	0.19	0.13
Loss on Drying	13-20	2.80%	16%	1.4	1.8

Conclusion

Oyster mushroom cultivation yields increased 100% by including **Neusilin®** in the cultivation process. It is likely that **Neusilin®** (FH1) provided buffering capacity in the mushroom growth media that helped maintained optimum pH conditions for significantly higher yields.

To obtain **Neusilin®** sample or to find your local distributor, please [contact us](#). For more technical information, please visit www.fujichemical.co.jp/english/neusilin.html

Meet us at CPhI WW 08



CPhI Worldwide 2008
Messe Frankfurt, Germany
30 September - 2 October 2008
Welcome to the source of new growth opportunities

Booth #42F42

*Please note our booth has been transferred to 42F42.

FUJI CHEMICAL INDUSTRY CO., LTD.

The information found in this publication is presented in good faith with no guarantee or obligation as to accuracy and no assumption of liability. Users should make their own tests to determine the suitability of these products for their own particular purposes. However, because of numerous factors affecting results, Fuji Chemical Industry makes no warranty of any kind, express or implied, including those of merchantability and fitness for particular purpose other than the material conforms to its applicable current standard specifications. Statements concerning the use of the products or formulations described herein are not to be construed as recommending the infringement of any patent and seller assumes no liability for the infringement arising out of such use.

F-MELT, Fujicalin and Neusilin are trademarks or registered trademarks of Fuji Chemical Industry Co., Ltd. in Japan, United States of America, Europe and/or other countries.

If you would prefer not to receive email newsletter, or you've changed your email address, please [click here](#)